

PARTS LIST

for

**MAYTAG<sup>®</sup>**


**COMMERCIAL  
ELECTRIC DRYER**

**MODEL NO.**

**MDE17CSAGW0**

# TOP AND CONSOLE PARTS

For Model: MDE17CSAGW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Model: MDE17CSAGW0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	W10131123	Nut, #8 U Type	29	W10111029	Harness, Timer
	W10184536	Instructions	15	W10139210	Screw, 8-18 X 5/16	30	W10135270	Timer & Harness Assembly
		Installation	16	W10135273	Panel, Rear (Upper)	31	W10145154	Cam, Commercial Lock
	W10163150	Wiring Diagram	17	3390647	Screw, 8-18 X 1/2	32	3351136	Door, Service
	W10184537	Repair Parts List	18	W10119283	Cover, Terminal Block	33	W10136649	Meter Case
2	W10146429	Nut, 8-32 X 3/8	19	W10223801	Screw, 8-18 X 3/8	34		Bolt, Meter Case Mounting
3	W10139799	Washer	20	717253	Receptacle (2-Way)		3353994	5/16-18 X 2 1/2
4	W10133502	Lens, Pilot Light Amber	21	357572	Clip, Ground		3349065	5/16-24 X 1.00
5	W10133507	Knob	22	3394427	Clip, Harness	35	3954812	Cushion, Meter Case
6	W10223798	Screw, 8-18 X 1/2	23	717253	Receptacle (2-Way)	36	W10139060	Nut, 1/4-20
7	W10135190	Facia / Overlay	24	3391018	Tie, Cable	37	W10133509	Funnel, Coin
8	W10124213	Bracket, Control	25	351297	Plug, Harness	38	W10111042	Harness, Main
9	W10139100	Screw, 8-32 X 1/4	26	3936144	Connector 3-Circuit	39	W10136707	Top
10	W10137919	Switch, Cycle Selection	27	3395683	Housing, Connector	40	3347825	Plate Mounting (2)
11	W10181931	Switch, Push-To-Start	28	W10154739	Bracket, Timer	41	98445	Screw, 10-16 X 3/4
12	W10139459	Lamp-Indicator				42	W10153513	Extension
13	W10205153	Console				43		Timing Cam
							3387974	Cam - 3 Pin
							343777	Cam - 6 Pin
						44	W10140928	Clip, Knob

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model: MDE17CSAGW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model: MDE17CSAGW0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3393008	Screw, 10-16 x 1/2	21	3389247	Hinge And Pin (2)	41	W10237959	Door Switch Assembly
2	W10131123	Nut, #8 U Type	22	W10131119	Screw, 8-18 X 5/16	42	W10118188	Screw, 6-20 x 1.00
3	3391846	Clip, Front Panel (2)	23	3391943	Boot, Foot	43	697215	Panel, Toe
4	3400077	Screw, 10-16 x 1/2	24	W10080540	Screw, 6-20 x 7/8	44	3387242	Seal, Front Panel
5	8318396	Foam-Seal	25	693152	Bumper	45	W10080310	Screw, 8-18 x 1/2
6	3397659	Block, Terminal	26	3389249	Nut, "U" (4)	46	3388229	Retainer
7	8310656	Cabinet	27	3404470	Motor Assembly (50 Hz.)	47	3392563	Door, Rear
8	3392100	Foot, Dryer (Plastic)	28	3402548	Pulley	48	694091	Screw, 8-18 x 3/8
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	29	8533974	Screw, 10-32 x 1/2	49	3387872	Door, Front
9	660658	Clamp, Motor (2)	30	W10131172	Belt, Drive	50	W10116360	Handle, Door
10	3387374	Spring, Idler	31	3390902	Clip, Door Hinge (2)	51	3393081	Front Panel
11	W10080670	Screw	32	3387118	Bracket, Motor	52	W10080240	Strike, Door
12	697750	Plug, Multivent	33	3392186	Washer	53	W10083220	Lever-Switch
13	3388672	Pulley Assembly	34	279318	Terminal, Brass & Tinned (3) (Includes Ill. 35)	54	3392538	Catch, Door Assembly
14	3391915	Screw, 10-16 x 1	35	279393	Terminal Block Screw Kit (For Terminal Block)	55	3390647	Screw, 8-18 x 1/2
15	3394331	Plate, Cover	36	3390663	Screw, 10-16 x 1/2	56	3390735	Seal, Door
16	3394081	Wire, Belt Switch	37	279731	4" - 90° Elbow	57	345670	Lock, Top
17	8316644	Clip, Strain Relief	38	3393657	Restrain, Belt	58	90406	Cage Nut
18	233520	Washer, Thurst	39	W10118754	Bracket, Idler	Optional Parts Not Included		
19	297092	Clip (2)	40	8318457	Switch-Belt	Dryer Exhaust Kit (For Side & Bottom Venting)		
20	690997	Tri-Ring				59	279818	White

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Model: MDE17CSAGW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Model: MDE17CSAGW0

(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	15	W10049370	Screen, Lint	29	W10119253	Bracket, Heater Box
2	90767	Screw, 8-18 x 3/8	16	W10206200	Thermostat 155°F Electronic	30	W10167627	Thermal Limiter
3	W10080820	Screw, 8-18 x 5/16	17	3387809	Bulkhead, Rear	31	487909	Screw, 8-15 x 1/2
4	8066086	Drum Hole Plug	18	W10080960	Washer, Support	32	W10168175	Thermostat 250°F
5	697354	Air Duct Assembly	19	8575325	Shaft, L.H. Thread	33	W10181926	Grill, Outlet
6	697813	Seal, Outlet Housing	20	690997	Ring, Tri	34	697557	Bulkhead, Front
7	697814	Seal, Drum Front	21	8536973	Roller, Support	35	697693	Baffle, Drum (3)
8	W10080210	Nut 3/8 x 16 (R.H.)	22	697770	Seal, Cover Plate	36	3357011	Screw, 10-16 X 1/2
9	W10121167	Exhaust Pipe	23	W10181927	Housing, Outlet	37	W10168564	Wheel, Blower
10	8572105	Clip	24	W10141623	Cut-Off, Thermal (Includes Illus. 32)	38	W10181925	Door, Lint Screen
11	693995	Screw, 8-18 x 3/8	25	8528998	Drum Complete	39	W10194158	Thermostat 140°F Cycling
12	3392537	Box, Heater	26	W10219342	Screw, 11-16 x 3/4	40	W10080640	Screw, 10-16 x 3/4
13	3390647	Screw, 8-18 x 1/2	27	W10166807	Seal, Drum	41	W10151271	Housing, Blower
14	3387749	Element, Heater	28	3394986	Spring, Lint Screen	42	8066168	Lint Duct Assembly
						43	8066208	Clip Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Model: MDE17CSAGW0

(White)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>

## ACCESSORY PARTS

4392067	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing

## PAINT, TOUCH-UP (1/2oz.)

72017	White
-------	-------

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

## PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST